

! WARNING

RISK OF ELECTRIC SHOCK

- DO NOT USE IN WET LOCATIONS.
- USE INDOORS ONLY.
- USE ONLY INSULATED STAPLES OR PLASTIC TIES TO SECURE THE CORDS.
- ROUTE AND SECURE THE CORDS SO THAT THEY WILL NOT BE PINCHED OR DAMAGED.

NON-REPLACEABLE PARTS

LED

LED LIGHT OUTPUT IS STRONG ENOUGH TO INJURE HUMAN EYES. PRECAUTIONS MUST BE TAKEN TO PREVENT LOOKING DIRECTLY AT THE LEDS WITH UNAIDED EYES FOR MORE THAN A FEW SECONDS.

SAVE THESE INSTRUCTIONS IN A LOCATION CLOSE TO YOUR CABINET SO YOU CAN REFER TO THEM AT A LATER TIME.

WARNINGS TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:

IMPORTANT SAFETY INSTRUCTIONS

This portable light has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug. Read entire installation procedure before you begin.

INSTALLATION PROCEDURE FOR PLUG-IN UNIT

Carefully plan out your installation prior to actually securing your LED Puck Light to the mounting surface, making sure that your 5ft. line cord will reach the nearest electrical outlet. For kitchen installations, the recommended mounting for the Puck Light is near the front lip of your kitchen under cabinets as shown in the illustration Figure 1. This provides the best light distribution across a countertop.

1. DO NOT ATTEMPT TO INSTALL FIXTURE WHILE PLUGGED IN.
2. Select a suitable dry mounting location (for use indoors only). Make sure mounting surface is capable of supporting the fixture.
3. Locate positions where LED puck should be mounted. (Keep in mind linking cord)
4. Use the enclosed template to mark the appropriate screw hole locations. Pre-drill holes in the mounting surface with a 1/16" (1.5mm) drill bit for soft woods and a 3/32" (2.4mm) drill bit for hard woods. Since mounting is via keyholes, the screw heads should protrude approximately 1/8" (3.2mm) beyond surface.
5. After installing mounting screws (included), secure the LED puck to mounting surface via keyholes. See Figure 2 and Figure 3.
6. Your line cord has a molded plug on one end with an in-line switch and a link connector at the other end. The link connector plugs in your LED puck. The two other cords are linking cords with link connectors on both ends. This is used to connect your LED puck to the next puck in your chain. Link adjacent pucks only. See Figure 5 below to see how the 2-pin and 3-pin plugs are intended to be used.
7. Attach the quick-connect power cord with the plug and 3-pin quick connector to the fixture closest to the outlet. See Figure 4 and Figure 5.
8. Install the next puck close enough to the initial puck for the 18" link cord to additional LED puck following steps 1-5 of the mounting instructions.
9. Once installed, attach the linking cord between the initial LED puck (previously installed) and the new one. See Figure 5 above to see how the 2-pin and 3-pin plugs are intended to be used.
10. Repeat steps 8-9 for the third puck.
11. When adding an additional LED puck to your existing 3 pack, the line cord (with the power plug) is not needed. Only the first LED puck in the chain needs to be connected to power with the line cord. Connect a maximum of 90 pucks together.
12. Plug fixture into a 120VAC 60Hz outlet.

Dimmable functionality:

1. For use of dimming function, please purchase the GE-branded under cabinet fixture junction box, part number 32612, and follow installation instructions to hardware your LED pucks.
2. Select a compatible LED dimmer.
3. Follow dimmer setup instructions for optimal performance.

Cleaning instructions:

Your fixture is made from quality materials that will last for many years with minimum care. When cleaning, make sure you have unplugged your fixture and have allowed sufficient time for the unit to cool to room temperature. You should clean the housing and lens using a soft, damp cloth. You should plug your fixture back in only after the fixture has thoroughly dried.

FCC NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.

MADE IN CHINA

GE is a trademark of General Electric Company and is under license by

Jasco Products Company LLC,

10 E. Memorial Rd., Oklahoma City, OK 73114.

This Jasco product comes with a limited-lifetime warranty. Visit www.byjasco.com for warranty details and product registration.

Questions? Contact us at 1-800-654-8483 between 7:30AM-5:00PM CST.

Figure 1

Figure 2

Figure 3

Figure 4

Figure 5

Figure 6

Figure 7

Figure 8

Figure 9

Figure 10

Figure 11

Figure 12

Figure 13

Figure 14

Figure 15

Figure 16

Figure 17

Figure 18

Figure 19

Figure 20

Figure 21

Figure 22

Figure 23

Figure 24

Figure 25

Figure 26

Figure 27

Figure 28

Figure 29

Figure 30

Figure 31

Figure 32

Figure 33

Figure 34

Figure 35

Figure 36

Figure 37

Figure 38

Figure 39

Figure 40

Figure 41

Figure 42

Figure 43

Figure 44

Figure 45

Figure 46

Figure 47

Figure 48

Figure 49

Figure 50

Figure 51

Figure 52

Figure 53

Figure 54

Figure 55

Figure 56

Figure 57

Figure 58

Figure 59

Figure 60

Figure 61

Figure 62

Figure 63

Figure 64

Figure 65

Figure 66

Figure 67

Figure 68

Figure 69

Figure 70

Figure 71

Figure 72

Figure 73

Figure 74

Figure 75

Figure 76

Figure 77

Figure 78

Figure 79

Figure 80

Figure 81

Figure 82

Figure 83

Figure 84

Figure 85

Figure 86

Figure 87

Figure 88

Figure 89

Figure 90

Figure 91

Figure 92

Figure 93

Figure 94

Figure 95

Figure 96

Figure 97

Figure 98

Figure 99

Figure 100

Figure 101

Figure 102

Figure 103

Figure 104

Figure 105

Figure 106

Figure 107

Figure 108

Figure 109

Figure 110

Figure 111

Figure 112

Figure 113

Figure 114

Figure 115

Figure 116

Figure 117

Figure 118

Figure 119

Figure 120

Figure 121

Figure 122

Figure 123

Figure 124

Figure 125

Figure 126

Figure 127

Figure 128

Figure 129

Figure 130

Figure 131

Figure 132

Figure 133

Figure 134

Figure 135

Figure 136

Figure 137

Figure 138

Figure 139

Figure 140

Figure 141

Figure 142

Figure 143

Figure 144

Figure 145

Figure 146

Figure 147

Figure 148

Figure 149

Figure 150

Figure 151

Figure 152

Figure 153

Figure 154

Figure 155

Figure 156

Figure 157

Figure 158

Figure 159

Figure 160

Figure 161

Figure 162

Figure 163

Figure 164

Figure 165

Figure 166

Figure 167

Figure 168